

## **EnviroCon T-Lock Installation Guide**

EnviroCon T-Lock is attached to most concrete forms with finishing nail prior to concrete placement. The finishing nails should be 1" or smaller. The nails must be driven flush with the back of the T-Lock to allow for their easy removal when the concrete forms are dismantled. The T-Lock should be attached at sufficient points to ensure a flush fit with the form.

EnviroCon recommends butt welding the adjoining ends of the T-Lock prior to pouring the concrete. The concrete surrounding the T-Lock should be vibrated to ensure that there are no void spaces adjacent to the T-Lock. After the concrete has set and the forms are dismantled, the finishing nails can be removed. If concrete gets between the EnviroCon T-Lock and the form, it should be chipped away to reveal the face of the T-Lock. Any sharp edges that are created by the chipping of concrete must be beveled to prevent possible cutting or puncturing of the liner.

[Click here for EnviroCon T-Lock Pricing Information](#)